

# Marine Operations Port Giles Port Rules

Uncontrolled if printed

## Legend

- P** denotes Pilotage activity
- V** denotes Vessel Traffic Management (scheduling) activity
- C** denotes Communications activity
- L** denotes Pilot Launch activity
- M** denotes Marine Services activity

# Table of Contents

|  |           |
|--|-----------|
| <b>1. Port Rules</b>   | <b>3</b>  |
| 1.1 <b>P V Purpose</b>   | <b>3</b>  |
| 1.2 <b>Scope</b>   | <b>3</b>  |
| 1.3 <b>Authority</b>   | <b>3</b>  |
| 1.4 <b>Powers of Port Management Officers (PMO)</b>                                  | <b>4</b>  |
| 1.5 <b>Pilotage Constraints</b>  | <b>5</b>  |
| 1.5.1 <b>Port Giles Pilotage Constraints</b>   | <b>5</b>  |
| 1.5.2 <b>Berthing Priorities</b>   | <b>5</b>  |
| 1.5.2.1 <i>Outports</i>  | <i>5</i>  |
| 1.5.2.2 <i>Port Adelaide, Port Giles and Wallaroo Grain Berth Loading Priorities</i> | <i>6</i>  |
| 1.5.3 <b>Pilot Passage Plan</b>  | <b>6</b>  |
| 1.6 <b>Geographic Limits</b>   | <b>7</b>  |
| 1.6.1 <b>Port Giles Port Operating Limits</b>  | <b>7</b>  |
| 1.7 <b>Communications</b>  | <b>7</b>  |
| 1.7.1 <b>Radio and Port Communications</b>   | <b>7</b>  |
| 1.7.1.1 <i>VHF Marine Channel Frequencies for Port Operations</i>                    | <i>7</i>  |
| 1.8 <b>Coordination of Marine Services</b>   | <b>8</b>  |
| 1.9 <b>Port Restrictions</b>   | <b>8</b>  |
| 1.9.1 <b>Vessel Dimensions &amp; Restrictions (Max)</b>                              | <b>8</b>  |
| 1.9.1.1 <i>Port Giles Maximum Vessel Dimensions &amp; Restrictions</i>               | <i>8</i>  |
| 1.9.2 <b>General rules for vessels in excess of port limitations</b>                 | <b>8</b>  |
| 1.9.3 <b>Tugs Required</b>   | <b>8</b>  |
| 1.9.3.1 <i>Specific Information – Commercial tugs in SA Ports</i>                    | <i>9</i>  |
| 1.9.3.2 <i>Tugs Required - Port Giles</i>  | <i>10</i> |
| 1.9.4 <b>Under Keel Clearance (UKC)</b>  | <b>11</b> |
| 1.9.4.1 <i>Port Giles</i>  | <i>11</i> |
| 1.9.5 <b>Launch</b>  | <b>11</b> |
| 1.9.5.1 <i>Port Giles Lines Launch Requirements</i>                                  | <i>11</i> |
| 1.9.5.2 <i>Launch in Attendance</i>  | <i>11</i> |
| 1.9.6 <b>Berths</b>  | <b>11</b> |
| 1.10 <b>Fleeting Requests</b>  | <b>11</b> |
| 1.11 <b>Vessel Navigation</b>  | <b>12</b> |
| 1.11.1 <b>Navigation</b>   | <b>12</b> |
| 1.12 <b>Notifications</b>  | <b>12</b> |
| 1.12.1 <b>Environment</b>  | <b>13</b> |
| 1.12.2 <b>Ballast</b>  | <b>13</b> |
| 1.12.3 <b>Divers</b>   | <b>14</b> |
| 1.12.4 <b>Dangerous Substances</b>   | <b>14</b> |
| 1.12.5 <b>Port Security Levels</b>   | <b>14</b> |
| 1.12.6 <b>Incident Reporting</b>   | <b>15</b> |
| 1.12.7 <b>Visitor Safety</b>   | <b>15</b> |

## 1. Port Rules

### 1.1 Purpose



Port Rules are intended to inform commercial users of the port of their responsibilities for the safe navigation of vessels within that port. These rules are a summary and are to be used as a guide only of the legislative/contractual agreements.

### 1.2 Scope



The port is operated in accordance with all laws in force in South Australia and any applicable Commonwealth or International laws, including but not limited to:

- Navigation Act 1912
- Harbors and Navigation Act 1993.
- Environment Protection Act 1993.
- Maritime Services (Access) Act 2000.
- Customs Act 1901.
- Quarantine Act 1908.
- Occupational Health, Safety and Welfare Act 1986.
- Protection of Marine Waters (Prevention of Pollution from Ships) Act 1987.
- South Australian Ports (Bulk Handling Facilities) Act 1996.
- South Australian Ports (Disposal of Maritime Assets) Act 2000.
- Recreational Access Agreement to Commercial Wharves Agreement.

### 1.3 Authority



Port Management Officers (appointed under Section 29 of the Harbors and Navigation Act 1993) will manage the port waters in accordance with the Act.

Port Management Officers are issued with a photographic identity card which lists the conditions of appointment.

Port Management Officers are responsible for directing and controlling vessel movements in port waters for the purpose of safe navigation of vessels.

This will include the:

- movement of vessels into, within and out of port waters;
- loading and unloading of vessels; and
- mooring, anchoring and securing of vessels within port waters.

Flinders Ports will ensure that adequate pilotage; mooring and towing services are available to fulfil the above requirements.

## 1.4 Powers of Port Management Officers (PMO)



A Port Management Officer may give a direction (orally, by signal, radio communication, or in any other appropriate manner) to a person in charge, or apparently in charge, of a vessel in or in the vicinity of the port. Failure to comply with a direction given by the PMO is an offence under the Act.

A direction may, for example:

- require that vessels proceed to load or unload in a particular order; or
- require that a vessel be moored or anchored in a particular position; or
- require that a vessel be secured in a particular way; or
- require that a vessel be moved from a particular area or position; or
- require the production of documents relating to the navigation, operation, pilotage, use or unloading of the vessel.
- if a person is not on board a vessel to receive a direction the PMO may cause the vessel to be moved and any costs recoverable from the owner.

A person in charge of a vessel must permit a Port Management Officer to:

- board the vessel; and
- inspect the vessel and its cargo; and
- carry out on the vessel any investigation necessary to ensure that the vessel and the business in the course of which the vessel is being used is being operated lawfully.

The appointment as a Port Management Officer confers upon the authorised persons all the powers of the following regulations, but only within the confines of the port nominated and only whilst under the management of Flinders Ports Pty Ltd. Further detail on the content of the regulations can be found on [www.transport.sa.gov.au/legislation](http://www.transport.sa.gov.au/legislation).

### Regulations:-

- Obstructions on wharves 15
- Obstruction of landing places 16
- Use of rail trolley 32
- Directions relating to dangerous or objectionable cargo 34
- Damage caused by cargo 35
- Traffic and other directions 49
- Removal of vehicles 51
- Permits 53
- Smoking and use of combustion equipment in hold 203

The following have been delegated to the Port Management Officers by the powers of the CEO (as referred to in the *Harbors and Navigation Act 1993 - "the Act"*) contained in the Regulations and any directly associated Regulation, stated below:

- Obstructions on wharves - 16(1)
- Obstruction of landing places - 17(1)
- Unauthorised activity on wharf - 18

- Use of rail trolley - 19(1)
- Abandoned cargo - 24
- Unauthorised entry to wharf or contiguous land - 25
- Watch officers in harbors - 26
- Mooring lines in harbors - 30(3)
- Restrictions in certain harbors - 31(1)
- Mooring and unmooring of vessels in certain harbors - 32(1)
- Swimming in harbors - 33
- Traffic signs - 34(1) and 34(2a)
- Parking signs and markings - 36(1)
- Permits (parking) - 38A(1) and 38A(2)

Note that these powers may only be exercised in the ports under the control of Flinders Ports Pty Limited and only by the person nominated below for that port.

| Name of Flinders Ports Employee   | Name of Port(s)                        |
|-----------------------------------|--|
| KAVINA Carl, DOW Douglas          | All South Australian commercial ports. |
| HAYWARD Gordon, PADMANABHAN Vijay | Port Pirie & Whyalla                   |
| COZZI Michael, MIERS Ben          | Port Lincoln and Thevenard             |

## 1.5 Pilotage Constraints



### 1.5.1 Port Giles Pilotage Constraints

A vessel 35m or more in length must not be navigated within Port Giles, unless the:

1. Master of the vessel holds a pilotage exemption certificate issued by DPTI for Port Giles.
  - a. Pilots can only be arranged through the vessel's owner/agent.
2. The vessel is navigated under the control, or at the direction of, a licensed pilot (a pilot licensed by DPTI for pilotage of vessels within Port Giles).
3. Unless expressly directed by a licensed pilot, boarding of vessels by the pilot will occur at the pilot boarding ground located 2.5nm East of the Pt Giles Jetty.

Prior to the vessel entering the port boundary and the vessel being under pilotage;

The licensed pilot must be onboard the vessel, and

The pilot and master exchange must occur to the satisfaction of the licensed pilot.

Note: A direction given for safety purposes must not be mistaken or construed as an "act of pilotage."

### 1.5.2 Berthing Priorities

#### 1.5.2.1 Outports

In an effort to minimise delays to all parties, Port Adelaide will have reasonable priority over outport locations, being the resident port for pilots and tugs which service these regions. The outport locations include, in order of priority, Port Giles, Wallaroo and Ardrossan.

### 1.5.2.2 Port Adelaide, Port Giles and Wallaroo Grain Berth Loading Priorities.

1. The principal of “first come, first serviced” will be strictly adhered to.
2. If a ship arrives to load grain cargoes it will automatically be deemed as being ready to load. If the loading berth is/becomes available, the first ship to arrive may occupy the loading berth.
3. Any vessel requiring the berth will be deemed as being ready to load and shall have the right to occupy the loading berth until proven different by surveys carried out by Australian Quarantine Inspection Service (AQIS), Australian Maritime Safety Authority (AMSA), or Marine Surveyors.
4. If the loading berth is subsequently required by another ship and the ship in the berth is not ready to commence loading due to major survey failure, that ship shall vacate the berth **at its own costs**, in order to allow the other ship to berth.
5. Major survey failure is any work required over and above a requirement to spray (e.g. Major hold cleaning, fumigation etc).
6. *Spraying means 6 hour spraying, with crew remaining on board.*
7. *Fumigation means 24 hour fumigation, with all crew vacating the ship.*
8. Vessels, which require spraying only will be allowed to perform the spray and re-survey at the loading berth.
9. If however on re-survey the vessel which has been sprayed fails and the berth is required by another vessel, it will be required to vacate the berth and return **at its own cost**.
10. A ship which is in the loading berth and declines to fully utilise the loading plant shall, if the loading berth is required by another ship which is prepared to survey and work (i.e. fully utilise the Loading Plant), remove and return **at its own cost** and allow the other ship to work the loading berth **until it has completed loading**. Rules are to apply on the basis of a 24 hour loading operation.
11. If the vessel, which takes the berth from another vessel also, fails, that vessel may stay at the load berth to perform tasks to pass survey, unless the berth is also required by a third vessel.
12. If a situation arises where there is a failed vessel at the load berth and another failed vessel at another berth undergoing tasks to pass surveys – the vessel, which passes survey first and obtains the “permission to load”, will be the vessel that has the right to occupy the load berth.
13. Subsequent arrangements made between agents may take precedence over 1 – 4.
14. Such arrangements are to be discussed with and agreed to by Flinders Ports before deviating from the loading priorities guidelines.

Flinders Ports shall be the final arbiter in deciding the priority and setting the consistency needed for the cost efficient operation of the loading berth.

### 1.5.3 Pilot Passage Plan

On boarding a vessel, the pilot will discuss a passage plan with the Ships Master, review the ship’s pilot card and exchange the normal pilot/master information,

Once satisfied the pilot will then commence the pilotage passage (inward/outward).

*Please contact Flinders Ports for a copy of the Pilot Passage Plan.*

## 1.6 Geographic Limits



### 1.6.1 Port Giles Port Operating Limits

The subjacent land underlying, and adjacent land extending from, the waters, rivers, creeks and inlets to high water mark of that portion of the western coast of Gulf St. Vincent bounded as follows:

*Commencing at a point on high water mark one nautical mile due south of the intersection of the centre line of the Port Giles Jetty with high water mark; then by a line bearing due east from high water mark for three nautical miles; then by a line bearing due north for two nautical miles; then by a line bearing due west to high water mark; then generally southerly along high water mark to the point of commencement.*

Refer to [Flinders Ports Website](#)

## 1.7 Communications



Flinders Ports Communication Tower, is manned at all times and maintains a listening watch on VHF channels 16 and 12 (call sign "Port Giles Port Control").

### 1.7.1 Radio and Port Communications



#### 1.7.1.1 VHF Marine Channel Frequencies for Port Operations

| VHF FREQUENCY   | PURPOSE   | NOTES  |
|---|---|--|
| Channel 16  | Calling - Distress & Safety                                   | Channel 67 for Distress & Safety                                 |
| Channel 12 Vessels should monitor VHF at all times in Port Limits for information | Ship/Shore/Ship Operations                                    | Transit advices/messages and information. Also Intership traffic |
| Channel 6 or 8  | Tug operations  | Primary channel - 6  |
| Channel 13  | Flinders Ports communications and Emergency Exercise/Response | To keep primary channels clear                                   |

All radio communications within the port will be conducted in standard marine navigation vocabulary as specified in the "Radio Telephone Ship Station Operators Handbook" (available from the Australian Communications Authority). Communication must be preceded by the identification of the channel the operator is using.

## 1.8 Coordination of Marine Services



Scheduling of vessel traffic is provided by CSO/MT (Central & Regional) during normal business hours (weekdays), and by the rostered CSO/MT throughout weekends and public holidays. The Communications Tower should be contacted at all other times.

Marine Services (pilotage, mooring, tugs, launches and communications) are all coordinated by Flinders Ports Client Services Officer located at 296 St Vincent St, Port Adelaide, during normal office hours (0830 - 1700, Monday to Friday) or the Communications Tower at all other times.

Flinders Ports operates a "One Stop Shop" for ordering and coordination of pilotage, tugs and mooring personnel. Whilst every effort is made to communicate resourcing advice in relation to prevailing conditions, it should be remembered that these services are only coordinated on the agents behalf and Flinders Ports is not responsible for cancellations due to adverse weather conditions.

## 1.9 Port Restrictions

### 1.9.1 Vessel Dimensions & Restrictions (Max)



#### 1.9.1.1 Port Giles Maximum Vessel Dimensions & Restrictions

Maximum length for Port Giles is 230m.

Vessels exceeding these lengths may be handled with permission of Flinders Ports. Conditions will apply.

Daylight berthing only in this port.

### 1.9.2 General rules for vessels in excess of port limitations



Oversize vessels are at the discretion of the GMMO (in conjunction with the duty pilot) and may be restricted to high water, daylight only, additional tugs, minimum cross currents, maximum wind speed of 15 knots, or any other restriction which may be prudent for the particular vessel. Vessels outside of the above parameters would be considered after simulations are carried out in a full mission ship simulator.

In the absence of the GMMO, approvals should be referred to the Chief Pilot.

### 1.9.3 Tugs Required



In the absence of alternative arrangements being approved by Flinders Ports, the following requirements are applicable.

A bow thruster will be considered in lieu of a tug provided its power is sufficient for the vessel's size and wind speed is less than 15 knots. Bow thruster power is calculated by the following:



1 HP = 0.746 KW

100 HP = 1 Tonne Bollard Pull

If a vessel has a bow thruster and visits a Flinders Ports port for the first time, the pilot will use appropriate tugs and assess the strength of the bow thruster.

If a vessel requires 3 tugs (1Z, 2 conventional) it can operate with 2Z's if they are available.

### 1.9.3.1 Specific Information – Commercial tugs in SA Ports

| Home Port     | Tug Name             | Year Built | LOA (metres) | M/E Power   | Bollard Pull | Propellers / Type       | Company | Remarks   |
|---------------|----------------------|------------|--------------|-------------|--------------|-------------------------|---------|---|
| Port Adelaide | <b>Burra</b>         | 2000       | 31.88        | 2X 1800 kW  | 63mt         | 2 / Z-peller            | Svitzer |   |
|               | <b>Svitzer Heron</b> | 2012       | 31.57        | 2X 1838 kW  | 65mt         | 2 / Z-peller            | Svitzer | Fire fighting equipped  |
|               | <b>Tingari</b>       | 2000       | 31.88        | 2X 1800 kW  | 60mt         | 2 / Z-peller            | Svitzer |   |
|               | <b>Walan</b>         | 1986       | 31.95        | 2X 1800 kW  | 49mt         | 2 / Z-peller            | Svitzer | Fire fighting equipped  |
| Wallaroo      | <b>Lucinda</b>       | 1975       | 23.77        | 2X 800 bhp  | 26.4t        | 2 / Nozzles             | PLT     |   |
| Port Pirie    | <b>Kuttabul</b>      | 1983       | 35.01        | 2X 2100 bhp | 55t          | 2 / Z-peller            | Svitzer | Harbour towage (priority PBV + PPI & WAL)                                   |
|               | <b>Tickera</b>       | 1976       | 28.98        | 2X 1250 bhp | 42t          | 2 / nozzles (steerable) | PLT     | Harbour towage (ex Tapir)   |
| Whyalla       | <b>Tarpan</b>        | 1984       | 32.17        | 2X 1342 kW  | 50t          | 2 / Z-peller            | Svitzer | Barging & harbour towage (WYA) / emergency towing (salvage) & fire fighting |
|               | <b>Wistari</b>       | 1982       | 34           | 2X 1343 kW  | 46mt         | 2 / Z-peller            | Svitzer | Barging & harbour towage (WYA) / fire fighting equipped                     |
|               | <b>Wonga</b>         | 1983       | 32.17        | 2X 1800 bhp | 50t          | 2 / Z-peller            | Svitzer | Barging & harbour towage (priority PBV + PPI & WAL) / fire fighting         |

|  |                         |      |       |            |       |                     |         |  |
|--|-------------------------|------|-------|------------|-------|---------------------|---------|--|
|  |                         |      |       |            |       |                     |         | equipped   |
|  | <b>Svitzer Ginga</b>    | 2006 | 30    | 2X 1685 kW | 55t   | 2 / Z-peller        | Svitzer | Barging & harbour towage (WYA / transshipping only) / fire fighting equipped |
|  | <b>Svitzer Larrakia</b> | 2006 | 30    | 2X 1685 kW | 55t   | 2 / Z-peller        | Svitzer | Barging & harbour towage (WYA / transshipping only) / fire fighting equipped |
|  | <b>Ungarra</b>          | 1968 | 20.96 | 2X 340 bhp | 12.5t | 2 / nozzles (fixed) | PLT     | Lines launch / PV & towage   |

|              |                |      |       |             |     |                         |     |  |
|--------------|----------------|------|-------|-------------|-----|-------------------------|-----|--|
| Port Lincoln | <b>Wangary</b> | 1976 | 28.87 | 2X 1250 bhp | 42t | 2 / nozzles (steerable) | PLT | 1st preference (ex Corsair)                      |
|              | <b>Bulimba</b> | 1979 | 29    | 2X 1250 bhp | 41t | 2 / nozzles (steerable) | PLT | Supplementary '2nd' tug / fire fighting equipped |
|              | <b>Kioloa</b>  | 1975 | 28.84 | 2X 1220 bhp | 40t | 2 / nozzles (fixed)     |     | Future uncertain, spare                          |

|           |               |      |       |            |     |                     |     |                         |
|-----------|---------------|------|-------|------------|-----|---------------------|-----|-------------------------|
| Thevenard | <b>Capel</b>  | 1976 | 25.68 | 2X 1500 hp | 34t | 2 / nozzles (fixed) | PLT | 1st preference          |
|           | <b>Warren</b> | 1971 | 25.3  | 2X 596 kW  | 28t | 2 / nozzles (fixed) | PLT | Supplementary '2nd' tug |

### 1.9.3.2 Tugs Required - Port Giles

In the absence of alternative arrangements being approved by Flinders Ports, the following requirements will apply.

#### Arrival

|   |   |
|---|---|
| <b>Vessels less than 150m LOA</b>   | To be berthed at slack water<br>No tugs required<br>(wind <15 knots)          |
| <b>Vessels of 150m to 200m LOA</b>  | To be berthed at slack water<br>With a draft less than 9m      1 tug required |
| <b>Vessels over 200m LOA, or exceeding 30m beam, or a draft of 9m or more</b> | 2 tugs required   |

Earliest scheduled POB time for this port is 0530.

## Departure

|   |  |
|---|--|
| Vessels up to, but not including Panamax size (<220m LOA)                   | No tugs required for departure   |
| Panamax size vessels (220m LOA x 32.28m)                                    | 1 tug on departure<br>Earliest scheduled departure time for this port is 0530.<br>Latest scheduled departure time for this port is 1930 hours due to tug availability. |
| Vessels exceeding the port limit of 230m LOA will be assessed individually. |  |

**1.9.4 Under Keel Clearance (UKC)****1.9.4.1 Port Giles**

|   |  |
|---|--|
| Vessels up to, but not including Panamax size (<220m LOA) | 0.6m UKC on departure<br>0.3m UKC whilst alongside |
| Panamax size vessels (220m LOA x 32.28m)                  | 10% UKC on departure<br>0.6m UKC whilst alongside  |

**1.9.5 Launch****1.9.5.1 Port Giles Lines Launch Requirements**

1 Line launch required when vessel is berthing.

**1.9.5.2 Launch in Attendance**

When a vessel is negotiating the channel or approaches to the channel with limited visibility and/or manoeuvrability a launch may be required to ensure the channel is clear of all other vessel traffic. Arrangements are to be made in advance.

**1.9.6 Berths**

Where applicable, restrictions against a specific berth may exist. Load limits apply to all wharves and jetties. For further information contact Flinders Ports on (08) 8447 0611 or refer to the berth information for [Port Giles](#).

**1.10 Fleeting Requests**

Masters and Agents must obtain permission from Flinders Ports before any repositioning of vessels by fleeting or warping occurs. Permission should be requested from the Client Services Officer/Marine Traffic, Port Management Officer or Communications Tower.

## 1.11 Vessel Navigation

### 1.11.1 Navigation



International Rules for the Prevention of Collisions at Sea Regulations apply to all vessels in all State waters, including those within Port Adelaide, unless indicated otherwise.

The master or operator of a vessel proceeding along the course of a river or channel must keep the vessel as near to the outer limit of the river or channel which lies on its starboard side as is safe and practicable.

The master or operator of a vessel, which can safely navigate outside a channel, must not allow the vessel to hamper the safe passage of a vessel which can safely navigate only inside the channel.

The master or operator of a vessel engaged in fishing must not allow the vessel to impede the passage of any other vessel navigating within a channel.

The master or operator of a vessel must not, except in an emergency, anchor the vessel in a channel.

If a vessel is anchored in a channel in an emergency, the master or operator of the vessel must, as soon as practicable, move the vessel to the side of the channel. The Communications Tower must be advised on (08) 8248 3505.

The master or operator of a vessel navigating in a channel must only overtake another vessel if this can be done safely.

A person must not, except with the approval of Flinders Ports, cause or permit a cable, chain, hawser or rope to be placed across a channel.

All vessels in ballast must have their propellers completely submerged and an appropriate trim by the stern. An appropriate trim for sailing is considered be 1% of the vessels overall length.

As far as practicable, it is recommended that gangways are kept inboard until all fast on arrival and until clear of the berth on departure.

## 1.12 Notifications



As a port authority, Flinders Ports will acknowledge a request to carry out certain activities e.g. Hot Work on a vessel via a "Notice". Such Notices can be requested by the ship's master through their agent asking for certain activities to be carried out on board the ship. These Notices are activity specific and act as a formal mechanism in identifying important provisions to be followed (& agreed to) in the interests of minimising safety risks to the vessel, its crew, other personnel and infrastructure.

Vessel agents are to complete the relevant Notice (which can be located on the [Flinders Ports website](#)) and fax it to Flinders Ports for acknowledgement.

Faxes are to be sent to:

### **During Office Hours**

The Duty Scheduler – Marine Operations      Fax: **8447 0603**

### **Out of Normal Working Hours**

The Communications Officer – Communications Tower      Fax: **8248 1623**

The recipient of the fax will assess if it is acceptable to proceed with the request - if it is OK, they will sign the Notice and fax back to the Agent.

No work is to commence until the signed copy is received by the Agent.

The required request forms to perform these certain functions can be located on the [Flinders Ports Website](#).

- Hot Work Notice (pdf)
- Bunkering Notice (pdf)
- Fumigation Notice (In port or in transit) (pdf)
- Immobilisation of Engines Notice (pdf)
- Chipping and Painting Notice (pdf)
- Lifeboat Drill Notice (pdf)
- Diving Notice (pdf)

#### **1.12.1 Environment**



Emissions and discharges:

- Vessels must not emit smoke or vapour to the extent that it causes danger to any other person.
- No offensive material is to be discharged from a vessel directly or indirectly into waters or onto land in the port.

#### **1.12.2 Ballast**



A Port Management Officer may give the master or operator of a vessel in a port directions relating to any ballast water carried on the vessel, including directions:

- prohibiting the discharge of ballast water into port waters; or
- requiring ballast water to be discharged in specified waters or in a specified manner (including that it is treated in a specified manner prior to discharge); or
- requiring ballast water to be exchanged in specified waters; or
- as to the loading of ballast water.

### 1.12.3 Divers



The Master or Operator of a vessel that is more than 10m in length is to inform Flinders Ports and request permission to carry out diving activities.

#### Signal when Divers Working

- The master or operator of a vessel that is over 10 metres in length must, at all times while a diver is operating from the vessel, display in a conspicuous position on the vessel the International Code Flag A.
- The master or operator of a vessel that is 10 metres or less in length must, at all times while a diver is operating from the vessel, display in a conspicuous position on the vessel a rigid replica of International Code Flag A, at least 750 millimetres by 600 millimetres in size.
- A diver who is operating in a harbour independently of a vessel must ensure that a rigid replica of International Code Flag A, at least 300 millimetres by 200 millimetres in size, is displayed at all times, from a buoy or float which is moored within 30 metres of the diver or is attached to a line and towed by the diver.
- A diver must not operate in a harbour, independently of a vessel, in a dredged channel used by vessels.
- The master or operator of a vessel navigating in the vicinity of a vessel, float or buoy displaying an International Code Flag A or a replica of that flag, must navigate so as to avoid injury to the diver or interference with the vessel, float or buoy.
- Where this regulation requires an International Code Flag A or a replica to be displayed, the person who is required to display the flag or replica must ensure that it is illuminated during the hours of darkness.
- All vessels passing another vessel which is displaying a diving signal shall pass at a speed not exceeding 4 knots and keep well clear.

### 1.12.4 Dangerous Substances



If cargo is of hazardous nature, details are to be provided to Flinders Ports by the agent for action as directed.

Cargo of an explosive nature is to be listed and will be forwarded (by Flinders Ports) to SafeWork SA. Hazardous cargo list(s) are to be forwarded to Flinders Ports by the vessel's agents at least 48 hours prior to vessel's arrival.

The list should provide all relevant details, including UN number to enable a check to be made. Flinders Ports has adopted the Standard AS 3846 "The Handling and Transport of Dangerous Cargoes in Port Areas".

### 1.12.5 Port Security Levels



The "Security Level" of the port as determined by the Office of Transport Security (OTS) as well as other current information can be accessed from the Flinders Ports web site on [www.flindersports.com.au](http://www.flindersports.com.au).

It is the obligation of any port user that observes a breach of security to report it promptly to Flinders Ports on (08) 8447 0600.

### **1.12.6 Incident Reporting**



The Master of a vessel has the responsibility to report any incidents via the Communications Tower on VHF Channel 16 or 12 or on phone (08) 8248 3505 that occurs on or near his/her vessel or a malfunction that can cause risk or damage to the vessel or port infrastructure.

Contact details and associated advice is documented in the "Notice to Masters of Ships" (FPFM 132) which is presented to Masters upon embarkation of the Pilot.

### **1.12.7 Visitor Safety**



All visitors or organised groups intending to be on the wharf while a ship is alongside a berth must provide notice of their intention and inform the Port Manager at least 24 hours prior to the visit to ensure a comprehensive assessment is made to ensure safety of all personnel on site.